



FIRE APPARATUS DRIVER/OPERATOR 1B

Pump Operations

PRESENTATION	APPLICATION
<ul style="list-style-type: none">3) Used when water flow exceeds 50% of rated capacity c) Net pump pressure should not exceed 50 psi when changing from volume to pressure or pressure to volume	<p>SLIDE: 2-1-25</p>